

**RoClean<sup>ä</sup> P112** is a powdered cleaner designed to remove silt and organic foulants such as colloidal silica, clays, organic color and bacterial slime from spiral wound thinfilm elements. This formulation is temperature compensated to ensure that the cleaning solution remains in the effective pH range regardless of variations in solution temperature.

### Performance:

RoClean™ P112 offers a variety of performance benefits:

- Compatible with the thinfilm elements of all major membrane manufacturers.
- Superior results in the removal of organic and colloidal foulants, especially when compared to generic solutions.
- Contains a specialized blend of buffers and other components to dissolve organic foulants and disperse colloidal particles.
- Highly buffered to resist pH changes during the cleaning process.
- Can be used in conjunction with other applicable cleaners as shown in the Avista cleaner selection guide.
- Temperature compensated to maintain optimum pH over a wide temperature range.

Total Systems International, LLC  
 1256 Bretmoor Way  
 San Jose, CA 95129 U.S.A.  
 Telephone: 1-408-996-0447  
 Facsimile: 1-408-996-0447  
 Email: Sales@TSI-LLC.us

### Use Instructions:

Below is a summary of the RoClean P112 cleaning guidelines. For detailed procedures, please consult the Avista technical bulletin entitled "Cleaning of Spiral Wound Membrane Systems"

1. Fill the cleaning tank to the desired volume with RO permeate or DI water. Heat the solution to 50°C as this will dramatically increase the cleaning efficiency. Add the RoClean P112 to the tank at a rate of 8.5 pounds per 50 gallons of water. Recycle the solution through the cleaning tank to ensure adequate mixing.
2. Recirculate the cleaning solution through each RO system stage, one at a time, for a minimum of 60 minutes at the flow rate recommended by the membrane manufacturer. If that rate is not known, use the guidelines listed below:

| Element Diameter, (Inches) | Flowrate per Vessel GPM (LPM) |
|----------------------------|-------------------------------|
| 4                          | 10 (38)                       |
| 6                          | 23 (87)                       |
| 8                          | 40 (151)                      |

3. If the membranes are heavily fouled and the recirculated cleaning solution becomes discolored or turbid, discard as much as 15% of the solution volume. Heavily fouled elements may also benefit from a soak period (up to 8 hours).
4. Monitor the pH of the solution during the cleaning process. If the pH remains in the desired range and the solution is not turbid, it may be used to clean subsequent stages. In the unlikely event that the pH falls below 12, prepare a new batch and repeat steps 1-4.
5. When the clean is completed, rinse the membranes by recirculating RO permeate through each pressure vessel. The system can then be returned to service.

### Dilution:

For moderate to severe fouling, RoClean P112 should be mixed at a rate of 8.5 pounds of chemical to 50 gallons of water. For milder fouling, a dilution of 4.3 pounds of chemical to 50 gallons of water may be sufficient.

### Packaging:

RoClean P112 is available in 45 pound pails.

### Properties:

Appearance: White to cream powder  
 Density: 62 pounds/ft<sup>3</sup>  
 pH: 12.0 - 13.0 (2% solution at 25°C)

